


# 3/8" AIR RATCHET WRENCH



Index No.	Parts No.	Description	Index No.	Parts No.	Description
1	32-301201	Housing	24	0HK0910	Needle Bearing
2	50102-12	Spring Pin (3*20L)	25	32-301228	Ratchet Housing
3	32-301203	Connection	26	33-310027	Crank Shaft
4	32-301204	Throttle lever	27	32-301226-12	Idler Gear Plate
5	32-301205	Valve Pin	28	32-301231	Drive Bushing
6	32-301210	Valve	29	32-301232	Yoke
7	32-301207	Valve Seat	30	32-301237	Ratchet Pawl
8	32-301208	Spring	31	32-301235	Spring Cap
9	OR02501108	O-Ring (25.12*1.78)	32	32-301239	Spring
10	32-302211	Deflector	33	32-301242	Washer
11	052213	Ball Bearing (696ZZ)	34	32-301233	Reverse Button
12	52245	Steel Ball(2) (3/32")	35	PN03030808	Pin (3.3*8.8)
13	0627ZZ	Ball Bearing (627ZZ)	36	70117	Spring Pin (2*5L)
14	52214	Rear End Plate	37	33-301238	Ratchet Anvil 3/8"
15	32-301215	Rotor	38	32-301234	Spring (2)
16	32-301216	Vane(4)	39	40145	Steel Ball(2) (1/8")
17	610225	Idler Gear Pin (3) (4*15.8L)	40	33-301241	Thrust Washer
18	32-301218	Cylinder	41	IRTW22	Retainer Ring (IRTW-22)
19	32-301219	Front End Plate	42	30117	Spring Pin (1.5*5L)
20	32-301224	Nut	44	32-301212	Bushing
21	32-301209	Cap	45	32-301252	Rubber Grip
22	32-301222	Thread Ring Gear	46	32-301243	Rubber Hat
23	32-301223	Idler Gear (3)			

33-3022-0001