


# 6" PALM SANDER



Index No.	Parts No.	Description	Index No.	Parts No.	Description
1	66-6133C01	Housing	27	SP03002800	Spring Pin (3×28)
2	SP03004000	Spring Pin (3×40L)	28	OR00500200	O-Ring (5×2)
3	66-6133C03	Air Inlet	29	66-6133C29	Lock Ring
4	66-6133C04	Throttle Lever	30	66-6133C30	Grip Hat
5	66-6133C05	Shaft	31	66-6133C31	Shroud
6	66-6133C06	Bushing	32	06001ZZ	Ball Bearing (6001ZZ)
7	OR02105105	O-Ring (21.5×1.5)	33	66-6132A13	Washer
8	OR01007105	O-Ring(2) (10.7×1.5)	34	66-6132A34	Shaft
9	52236	O-Ring (10.5×1)	35	60-613135	Snap Ring
10	66-6133C10	Regulator	36	61934	Key
11	66-6133C23	Exhaust Shafte	37	66-583737	Balancer Shaft
12	66-6133C12	Adapter	38	60-613139	Washer (3×13)
13	51542	Spring Pin (2×18L)	39	66-6133C25	Muffler
14	66-6133C14	Rear End Plate	40	66-6132A54	Spanner
15	66-6132A15	Rotor	41	OR03904301	O-Ring (39.4×3.1)
16	66-6132A16	Rotor Blade(5)	42	40130	O-Ring (8.8×1.7)
17	66-6133C17	Screw (M5×10)	43	OR00200100	O-Ring (2×1)
18	66-6133C18	Cylinder	44	66-6133C07	Muffler
19	66-6133C19	Front End Plate	45	82247	O-Ring (13.5×1.5)
20	66-6133C20	Swivel Exhaust	46	82209	O-Ring (14×1)
21	OR00307108	O-Ring (3.68×1.78)	47	76010	O-Ring (5.8×1.9)
22	STW14	Retaining Ring (STW-14)	48	66-6133C24	Exhaust Sleeve
23	66-6133C08	Spring	49	06001	Ball Bearing (6001)
24	66-6132A12	Retainer Ring	50	06001P	Ball Bearing (6001P)
25	66-6133C32	Nut (M5×0.8)	*51	60-613142	Pad (6")
26	06000ZZ	Ball Bearing (6000zz)	52	66-6133C22	Stopper

\* optional part

66-6833C-0001

04.15.2010