


3" REVERSIBLE FLEX HEAD CUT-OFF TOOL



Index No.	Parts No.	Description	Index No.	Parts No.	Description
1	5K33R01	Housing	29	0BA86	Needle Bearing (2) (BA86)
2	30102	Spring Pin (3x24L)	30	PN03000600	Pin (3x6L)
3	5K33R03	Air Inlet	31	5K33R31	Spring
4	6K-301104	Throttle Lever	32	5K33R32	Spacer Ring
5	5K33R05	Valve Shaft	33	5K33R33	Clamp Nut
6	5K33R06	Bushing	34	5K33R34	Socket Joint
7	68-6138A13	Screw (M4x10L)	35	5K33R35	Flex Spacer (2)
8	5K33R08	Spring	36	5K33R36	Screw (2) (ST3x6L)
9	5K33R09	Muffler	37	ISTW-22	Inverted Retaining Ring (ISTW-22)
10	5K33R10	Exhaust Diffuser	38	5K33R38	Screw (2)
11	OR01300103	O-Ring (2) (13x1.25)	39	51542	Spring Pin (2x18L)
12	5K33R12	Knob	40	5K33R40	Washer (4)
13	OR03105108	O-Ring (31.47 x 1.78)	41	5K33R41	Power Shaft
14	5K33R14	Rear End Plate	42	5K33R42	Flex Shaft
15	5K33R15	Rotor	43	56226	Spanner (2) (11mm)
16	5K33R16	Vane (4)	44	5K33R54	Screw
17	706107	O-Ring (2) (12x2)	45	5K33R45	Lock Sleeve
18	5K33R18	Cylinder	46	5K33R46	Spring
19	5K33R19	Front End Plate	47	5K33R47	Clamp Nut
20	OR00600200	O-Ring (6x2)	48	5K33R48	Bushing (2)
21	OR01007105	O-Ring (10.7x1.5)	49	5K33R49	Drive Shaft
22	SP02002200	Spring Pin (2x22L)	50	5K33R50	Drive Flange
23	030113	Ball Bearing (626ZZ)	51	5K33R51	Flange
24	63062	Spring Pin (2) (3x6L)	52	5K33R52	Grip
25	060313	Ball Bearing (6001ZZ)	53	5K33R53	Guard
26	80235	Steel Ball (2) (1/4")	54	522239	Safety Bar
27	5K33R02	Retaining Ring (2) (STW-1/2)	55	522212	Spring
28	70123	O-Ring (2) (11.8x2.4)	*56	52630	Cutting Wheel (3")

*Optional Parts

5K33R-0001

08.12.2019.B